

# Operating Instructions

6000g VACUUM PYCNOMETER ATTACHMENT

Model: 45-9315/10 (AP-912)

Rev. 0: 10/04

<p><b>ELE International, Inc.</b> PO Box 608 Loveland, CO 80539 USA Phone: (970) 663-9780 Fax: (970) 663-9781 E-Mail: <a href="mailto:soiltest@eleusa.com">soiltest@eleusa.com</a> Website: <a href="http://www.eleusa.com">www.eleusa.com</a></p>	<p><b>Distributor:</b></p>	<p><b>ELE International, Ltd.</b> Chartmoor Road Chartwell Business Park Leighton Buzzard, Bedfordshire LU7 4WG England Phone: + (0) 1525 249200 Fax: + (0) 1525 249249 E-Mail: <a href="mailto:ele@eleint.co.uk">ele@eleint.co.uk</a> Website: <a href="http://www.eleint.co.uk">www.eleint.co.uk</a></p>
--	----------------------------	--

---

## 6000 GRAM VACUUM PYCNOMETER ATTACHMENT MODEL 45-9315/10 (AP-912)

---

### I. GENERAL INFORMATION

The 6000 Gram Vacuum Pycnometer Attachment, model 45-9315/ (AP-912), is used to install the 45-9300 (AP-132) Vacuum Pycnometer on the 45-9315/ (AP-910A) Vibrator.

### II. RELATED USER DOCUMENTATION

These operating instructions do not contain the necessary information on specific test procedures. Please refer to ASTM D-2041 for test information.

### III. INSTALLATION

- A. Unscrew two 1/4-20 hex nuts from underneath the vibrator table and remove two uprights and the round bracket.
- B. Attach the clamping disc to the vibrating table, using the flat screws 1/4-20 which are provided.
- C. With supporting nuts, install the two uprights to the clamping disc.
- D. Install the upper clamping disc and the quick acting knobs.

**NOTE:** Always use and properly adjust the back-up nuts to prevent upper clamping disc damage.

<p><b>ELE International, Inc.</b> PO Box 608 Loveland, CO 80539 USA Phone: (970) 663-9780 Fax: (970) 663-9781 E-Mail: soiltest@eleusa.com Website: www.eleusa.com</p>	<p><b>Distributor:</b></p>	<p><b>ELE International, Ltd.</b> Chartmoor Road Chartwell Business Park Leighton Buzzard, Bedfordshire LU7 4WG England Phone: + (0) 1525 249200 Fax: + (0) 1525 249249 E-Mail: ele@eleint.co.uk Website: www.eleint.co.uk</p>
---	----------------------------	--